

# TOWEL WARMER INSTALLATION INSTRUCTIONS

## INFORMACION IMPORTANTE



THIS TOWEL WARMER IS MADE OF MILD STEEL AND IS ONLY SUITABLE FOR USE ON CLOSED HEATING SYSTEMS WITH A CHEMICAL WATER TREATMENT INHIBITOR ADDED TO PROTECT AGAINST CORROSION, SCALE AND SLUDGE

**FAILURE TO FLUSH OR MAINTAIN ADEQUATE LEVELS OF CORROSION INHIBITOR WILL ALLOW FOR SMALL PINHOLE LEAKS TO BE CAUSED INVALIDATING ANY WARRANTY**



Installation should be carried out by a qualified professional or other fully competent person and should be installed in accordance with the relevant British and European Standards (BS5449:1990, BS7593:2006, EN12828:2003 & EN12831:2003)









Please ensure that you wear all necessary personal protective equipment for your safety. Please check that all components are present and that you are entirely happy with the size, design and finish before starting installation.

### PACK CONTENTS

1 x Towel Warmer	3 x Bracket Front (c) 	3 x Wall Screw (f) 	3 x Mini Screws (i) 
3 x Bracket Base (a) 	3 x Bracket Cover (d) 	3 x Washer (g) 	1 x Air Vent Plug (j) 
3 x Bracket Stem (b) 	3 x Wall Plug (e) 	3 x Bracket Screw (h) 	(k) 1 x Blank Plug 

### FITTING THE TOWEL RAIL ON TO THE WALL


<p><b>STEP 1.</b> Screw the Blank Plug (j) and Air Vent Plug (k) into the top two threads in the upright channels. Tighten firmly with a spanner, using a cloth to prevent scratching.</p>	
<p><b>STEP 2.</b> Wind a thick layer of PTFE tape (at least 6 turns), clockwise around the radiator valve tails (not supplied). Screw the radiator valve tails into the bottom two threads and tighten with a spanner.</p>	

<p><b>STEP 3.</b> Select your desired mounting position and check that the wall is sufficiently strong enough to hold the weight of the towel warmer filled with water. Mark your preferred bracket positions on the wall and drill holes as necessary for the fixings that you are using. The Wall Plugs (e) supplied are only suitable for solid walls. Please note: If the wall is other than a solid construction other means of fixings will be required.</p>	
<p><b>STEP 4.</b> Screw the Bracket Base (a) to the wall using the Wall Screws (f) and Washers (g) provided.</p>	
<p><b>STEP 5.</b> Loosely fit the Bracket Stems (b) to the towel warmer with the Bracket Fronts (c) and Bracket Screws (h). Rotate the bracket stems as per the figures below.</p> <div style="text-align: center;">  <p><b>FLAT RAIL</b>                      <b>CURVED RAIL</b></p> </div>	
<p><b>STEP 6.</b> Align the Bracket Stems (b) with the Bracket Bases (a) and push the towel warmer back into position.</p>	
<p><b>STEP 7.</b> Tighten the Bracket Screws (h) with a screwdriver.</p>	
<p><b>STEP 8.</b> Insert the Mini Screws (i) into the Bracket Bases (a) and tighten with a screwdriver to lock bracket into position.</p>	
<p><b>STEP 9.</b> Push the Cover Caps (d) into position on the Bracket Fronts (b).</p>	
<p><b>STEP 10.</b> Connect the radiator valves (not supplied) and after installation vent any air from the towel warmer via the Air Vent Plug.</p>	

### CARE AND MAINTENANCE

AFTER INSTALLATION THE CENTRAL HEATING SYSTEM MUST BE THOROUGHLY FLUSHED WITH A DOMESTIC WATER TREATMENT ASSOCIATION APPROVED CENTRAL HEATING CLEANSER. FOLLOWING CLEANSING A DOMESTIC WATER TREATMENT ASSOCIATION APPROVED CENTRAL HEATING PROTECTOR MUST BE ADDED TO THE SYSTEM.

Central heating protector levels should be checked periodically in line with the manufacturer's recommendations. Regular cleaning with a soft cloth will keep the surface of your towel warmer looking new. Soapy water can be used to remove stubborn stains and then buff dry with a soft cloth. Do not use abrasive or chemical cleaners to clean your towel warmer as these will damage the surface finish over time.

 Most units can be installed so that the rail can be heated electrically when the central heating is switched off or just for standalone electrical use with a dual fuel electrical element kit (sold separately). Please refer to the kit for installation instructions.